

Technical Data Sheet



Stain Solve D™

Stain Remover for Medical and Specialty Stains

This product is an alkaline laundry stain remover formulated to treat stains from medicines, ointments, lipstick, grease and more. Designed for use in institutional and industrial laundry applications, especially in healthcare settings. Safe for use on bed linens, towels, blankets, smocks, uniforms, rags, coveralls, etc. Effectively penetrates and dissolves soils prior to washing. Fortified with powerful solvents, surfactants and pH builders for rapid penetration and removal of stubborn soils. Rinses completely in the wash, leaving clean fabric behind. An essential product for maintaining spot-free laundry without damaging fabric. Non-flammable and non-toxic. Biodegradable.

Directions for Use

Prior to use, test this product in an inconspicuous area to assure compatibility with fabric to be treated.

Prespotting: Apply liberally on to stains. Allow to remain on fabric for 5-10 minutes prior to laundering.

Presoaking: For heavily soiled or stained fabric, this product may be used at full strength or diluted at 2:1 with hot water. Place stained laundry into soaking vessel, then pour this product into vessel, immersing fabric completely. Allow to soak for at least 30 minutes, up to 8 hours, then launder as usual.

Safety Reminder

Consult product label and Safety Data Sheet (SDS) before use. SDS's can be downloaded from www.crown-chem.com.

**THERE'S A
STAIN SOLVE
FOR EVERY
STAIN!**



Technical Specifications

Appearance	Yellow Liquid
Odor	Characteristic
pH (1% solution, 22°C)	>11.5
Foaming	Moderate
Flash Point	>200°F
Density (lbs/gal, 22°C)	9.09 ±0.1
Stability Range	50-100°F
Free Alkalinity (as Na ₂ O)	<2.0%
Solubility (in H ₂ O, 22°C)	100%
Phosphate Content (as P)	None

Product Number

21406

*One sprayer included per case

Packaging

6x1 qt. case*



4701 W. 136th Street • Crestwood, IL 60445
tel (708) 371-6990 • (800) 672-4065
fax (708) 371-6992
www.crown-chem.com

